

MugGuard Rear - Fitting Instructions

1. Take the 2 arms and insert the rubber grips making sure the holes line up correctly. Note that the arms and the grips are sided, marked "L" and "R".



2. With the arms fitted with the rubber grips, take the short unit and insert the arms on the inside, lining up the holes and ensuring that the teeth are correctly meshed. Make sure you line up the dial in points to one of the suggested markers. Note which marker you have used and insert the other arm to the other side using the same dial in point.



3. It's a good idea at this stage to clip in the long extension, which slides and slots into position. This will help later when the guard is on the bike so you can adjust the angle and clearance.



4. You can now fix the MugGuard to the bike. You should at this point get a better idea of the angle required to line the guard up to match the curve of the wheel and the clearance you require. If it doesn't line up, just simply remove the arms, adjust the dial in angle using a different dial in point. Do this until you are happy the MugGuard fits as expected.
5. With the MugGuard in position, you can now plug the dial in points with the buttons supplied. These will snap into position and lock in everything together. Please check that this is done correctly and ensure that the face is flush with the guard.
6. Time now to use the Velcro supplied to attach the host guard to the bike. You will need 4 strips of Velcro so we suggest unravel the roll, fold it in half and cut, then fold those 2 pieces in half and cut again.

7. Pass the Velcro through each hole on the arms, and loosely connect the Velcro so we can adjust the arms position if necessary. Once each arm is attached to the bike, simply slide the arms into the best position for your bike. When your happy then simply tighten the Velcro.



8. If you wish to swap out the long guard for the shorter version, then depress the connector button on the top of the guard and slide the long guard out and do the reverse to put the short guard into position.
9. If you still have trouble putting the MugGuard Rear together, we can always try to help, just give us a call on +44 (0) 1288 488060

Enjoy the ride!